

### **AIA Documents**

#### **A Series**

- Owner & Contractor Documents (including bond forms)
  - A201
    - ➤ Project General Conditions Integrates with most forms

### **B** Series

- > Owner & Architect Documents
  - B101
    - > Owner-Architect Agreement Most common design agreement

#### **C** Series

> Other Agreements (subcontractors, consultants, construction manager-not at risk )

#### **G** Series

> Standard Forms - Payment Documentation, Change Orders, RFIs

**PERKINSCOIE** 

# The A-Series Owner-Contractor Contracts Related To Project Payment Method

#### **AIA A101**

Standard Form of Agreement Based on a Stipulated Sum (Lump Sum)

#### **AIA A102**

➤ Standard Form of Agreement Based on the Cost of the Work Plus a Fee with a Guaranteed Maximum Price (GMP)

#### **AIA A103**

Standard Form of Agreement Based on the Cost of the Work Plus a Fee without a Guaranteed Maximum Price

### **AIA A104**


Standard Abbreviated Form of Agreement Between Owner and Contractor – Can be any of the three payment methods

### AIA A141, 141/2 - 2014

Standard Form of Agreement Between Owner and Design-Builder

# 2017 B-Series Owner-Architect Agreements – Related to Project Size

#### LARGE PROJECTS





## **Pricing Variations in Construction Contracts**

### Fixed Price contracts (lump sum) (A101)

- Contractor bears risk of cost overruns
- Contractor has possibility of windfall profits
- Can more readily lead to adversarial relationships between owner and contractor
- Change orders modify what the Contractor is actually paid

### Cost-plus contracts (time & materials – cost of the work) (A102 & A103)

- > Fee can be a percentage, fixed sum, or any agreed-on formula
- ➤ May have a cap know as a Guaranteed Maximum Price (GMP) (A102)
- > Can be difficult for owner to control costs unless there is a GMP
- May have a savings sharing clause with GMP agreements
- Change orders for cost of the work Contractor paid for the work performed
- Change orders for GMP agreements only change the GMP and may not change payment actually paid to the Contractor

## **Pricing Variations in Construction Contracts**

### **Unit Prices**

- > Owner pays a specified cost for a particular quantity of work
- > Best for repetitive types of work (concrete, roadways, etc.)





## Competitive Bidding – Traditional and Fast-Tracked Methods

## Competitive Bidding – Required for Public Projects; May be used with Private Projects

- Lowest Responsible and Responsive Bidder
- Best Value Method Design Build (not allowed in all states for public projects)
- Exception sole source contracts (very rare in public projects)

## Purpose: To achieve the lowest cost, and an impartial forum for contractor selection

### "Short-Listing" of bidders – before and after the RFP process

- Pre-qualification process
- After proposals are received

## Competitive Bidding – Traditional and Fast-Tracked Methods

### The typical process

- Invitation to bidders
- Submittal of bids/proposals
- Opening of bids/proposals
- Evaluation of bids/proposals
- Notification of award of project
- Signing a formal contract



## Competitive Bidding – Traditional and Fast-Tracked Methods

### Bidding errors – How are they addressed?


- Bids with clerical/arithmetic errors may be withdrawn (but not modified)
- Bids with judgment errors cannot be withdrawn
- Exception The "snap-up" rule allows a party to withdraw its bid (where the owner should have known of the bidding mistake by comparison to other bids – gross disparity)







### **Traditional Owner-Architect Contractor**



### Traditional Owner-Architect Contractor

### **Advantages**


- It is common, so the marketplace is comfortable with it
- Plans are usually complete prior to bidding or final pricing
- Architect remains independent
- Will work with lump sum, cost of the work plus, and GMP agreements


### **Disadvantages**

- Often little input from contractor during design
- Slower delivery time due to linear / back-to-back phasing
- Can create an adversarial relationship between G.C. and A/E
- Price competition reduces profits or renders some projects unobtainable
- Claims Contractors low bid, but is the bid accurate
- Truth in Bidding




## Owner – Developer Model







## Traditional v. Fast Tracking



- Traditional linear
- Fast-Track overlapping
- Fast-Track Advantage Delivery speed of a completed project.
- Fast-Track Disadvantage More difficult to control cost estimating and construction costs.




### Owner – Multi-Prime Model



- No role for the general contractor
  - Owner has all contracts directly
  - There may be legal reasons for this contracting method
- Owners rarely are able to successfully manage and coordinate project
- Owner liable for management and coordination problems during construction
  - Time and cost management




## Construction Management – Agency CM Model




- Retained to manage the construction
- Does not enter into the agreements with the trade contractors
- Also referred to as an Owner's Representative
- On-site observer similar to architect's role
  - Time and cost management

## Construction Management – At Risk CM Model




## Construction Management – Risk Spectrum



to manage costs.



## Traditional Design-Build Model







## Design-Build Relationships – Various Types

- > Integrated Company
- > Contractor is the Prime, A/E is the Sub
- > A/E Prime is the Prime, Contractor is the Sub
- > A/E is the Prime, Multiple Trade Subs retained
- Design-Builder Prime, A/E and Contractor Each Subs (Multiple Integrated Company)
- > Joint Venture between A/E and Contractor (joint and several liability)

## Multiple Integrated Company Model



## Multiple Integrated Company Model



## Advantages of Design-Build

- Speed of project delivery
- Owner can look to design-builder for single-point responsibility
- > Obtain cost certainty earlier and with better results
- Better communication of design intent from the design arm to constructing arm
- Less litigation and/or disputes
- Greater control of information by design-build team
- > Negotiated pricing
- > A/E and GC not adverse to one another

## Disadvantages of Design-Build

- ➤ Loss of architect as independent decision maker or "policing body" on the project
- > Pricing may be suspect depending on when the fast-tracking took place
- > May be more of an economic risk depending on the design-builder entity
- > Who is back-checking for the owner?

# Design-Build: Differences in Architect's Design Phase Services

- > System-by-system design with "looping" feedback
  - > Each system is designed semi-independently
  - > Design of each system constantly modified by feedback from the construction team
- > Informal communications rather than "defensive detailing"
- > Greater incentive to explore alternative design concepts
- ➤ MEP/FP only schematic, and is ultimately designed and built by specialty subcontractors

# Design-Build: Differences in Architect's Design Phase Services

- > Greater than usual pricing constraints and price input
- ➤ Out-of-sequence provision of design details to meet contractor's need to price the project
- ➤ Heavier than usual reliance on performance specifications



